

READ AND SAVE THESE INSTRUCTIONS

Digital Timer, BDT-1

Features

- 24 hour operation
- Up to 8 ON/OFF settings every day of the week
- Cycles from 1 minute to 7 days
- Maximum Load: 1725W/15A/115V
- Rechargeable NiMH battery saves programmed settings in case of power loss

Using the Blueprint Digital Timer

Before Use

Plug unit into outlet and allow internal battery to charge for at least 2 hours before setting time.

Set Current Time and Day

1. Press “CLOCK” and “HOUR” at the same time to set the hour.
2. Press “CLOCK” and “MIN” at the same time to set the minute.
3. Press “CLOCK” and “WEEK” at the same time to set the day of the week.

Program ON/OFF Cycles

1. Press “PROG” to enter the “ON” setting mode. The display will show “1 ON.”
2. Press “HOUR” to cycle through and select the desired hour at which the timer will activate. Repeat with the “MIN” button.
3. “Mo, Tu, We, Th, Fr, Sa, Su” will display. This will set the timer to operate daily.
4. Press “WEEK” to cycle through and select a single day on which the timer will activate. Continue to press “WEEK” to cycle through and select one of various combinations of days.
5. Press “PROG” to enter the “OFF” setting mode. The display will show “1 OFF.”
6. Use “HOUR,” “MIN” and “WEEK” to set the hour, minute and day(s) of the week on which the timer will turn off.
7. Repeat steps 1-6 to program up to 7 additional ON/OFF cycles.
8. When in “PROG” mode, press “R” to delete the displayed timer setting. Press “R” again to return to setting mode.

Select Timer Mode

Press “ON/AUTO/OFF” to cycle through timer modes.


- Select “ON” to keep timer constantly on.
- Select “AUTO” to run timer as programmed.
- Select “OFF” to turn timer off.

Random Function

Press “HOUR” and “WEEK” at the same time to show “o” on the right hand side of the display. This will randomly extend ON and OFF settings by 2 to 32 minutes.

Reset Function

Press the small recessed button below the “R” button to default to factory settings.



Blueprint Controllers® Digital Timer Limited Warranty

What This Warranty Covers

This warranty covers defects in materials and workmanship under normal use, with the exceptions stated below.

Who This Warranty Covers

This warranty applies to the original purchaser of this product with the original proof of purchase.

How Long Warranty Coverage Lasts

This warranty is in effect for a period of one years from the original date of purchase.

What This Warranty Does Not Cover

This warranty does not cover damage or defects resulting from the improper installation, alteration, abuse, accidental damage, unauthorized repair or misuse of this product. Misuse includes but is not limited to outdoor use. This warranty does not apply to cosmetic defects or other defects that do not affect the functionality of the product, and is void if the product has been damaged as a result of fire, flood, or other natural disaster. BWGS shall not be responsible for any incidental or consequential damages of any nature, including damage or injury caused to other products, machinery, buildings or property; loss of profits, time or product; or inconvenience. The original proof of purchase MUST accompany the Blueprint product for this warranty to be valid. This warranty is given in lieu of all other warranties, express or implied, including without limitation merchantability and fitness for a particular purpose.

Some states do not allow the exclusion or limitation of incidental and consequential damages, or limitations on how long an implied warranty lasts, so the above limitation(s) may not apply to you.

What BWGS Will Do

If BWGS determines the warranted product is defective in materials or workmanship during the warranty period, then BWGS, at its option, will either repair or replace the product. In no event shall the cost of repair or replacement exceed the original purchase price.


How to Obtain Warranty Service

Return this product along with the original proof of purchase to the place of purchase in accordance with store policy.

How State Law Applies

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For technical support and warranty information, call toll-free 888-464-9676 or email info@bwgs.com.



blueprintcontrollers.com