



READ AND SAVE THESE INSTRUCTIONS

# MECHANICAL TIMER

## 240V, BMT-1C

Blueprint Controllers® put the power of automation to work in indoor garden environments everywhere. For safety and optimal performance, please carefully read this document **in full** before installing and operating this product.

### Using This Mechanical Timer

#### Set Current Time and Day

This mechanical timer uses a 24-hour format. Turn the numeric dial to align the arrow  with the current time of day.

#### Program ON/OFF Cycles

For cycled power, set the switch on the right side of the unit to **TIMER**. Push trippers downward to set ON cycles for the corresponding times on the numeric dial. Push down all trippers between the desired start and stop times to create an extended ON cycle, or alternate tripper positions for any combination of ON/OFF cycles.

For continuous power, set the switch on the right side of the unit to **ON**. This will bypass any tripper settings and allow the unit to supply constant power to the connected device.



#### **WARNING**

This product is for indoor use only.  
Use only in a dry location.  
Do not overload.

# Blueprint Controllers® Mechanical Timer Limited Warranty

## What This Warranty Covers

This warranty covers defects in materials and workmanship under normal use, with the exceptions stated below.

## Who This Warranty Covers

This warranty applies to the original purchaser of this product with the original proof of purchase.

## How Long Warranty Coverage Lasts

This warranty is in effect for a period of one year from the original date of purchase.

## What This Warranty Does Not Cover

This warranty does not cover damage or defects resulting from improper installation, alteration, abuse, accidental damage, unauthorized repair or misuse of this product. Misuse includes, but is not limited to, outdoor use. This warranty does not apply to cosmetic defects or other defects that do not affect the functionality of the product, and is void if the product has been damaged as a result of fire, flood, or other natural disasters. BWGS shall not be responsible for any incidental or consequential damages of any nature, including loss of profits, time or productivity; inconvenience; or damage caused to other products, machinery, buildings or property.

The original proof of purchase MUST accompany the Blueprint product for this warranty to be valid. This warranty is given in lieu of all other warranties, express or implied, including without limitation merchantability and fitness for a particular purpose.

*Some states do not allow the exclusion or limitation of incidental and consequential damages, or limitations on how long an implied warranty lasts, so the above limitation(s) may not apply to you.*

## What BWGS Will Do

If BWGS determines the warranted product is defective in materials or workmanship during the warranty period, then BWGS, at its discretion, will either repair or replace the product. In no event shall the cost of repair or replacement exceed the original purchase price.

## How to Obtain Warranty Service

Return this product along with the original proof of purchase to the place of purchase in accordance with the store policy.

## How State Law Applies

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**For technical support and warranty information, call toll-free 888-464-9676 or email [info@bwgs.com](mailto:info@bwgs.com).**

