



THANK YOU FOR CHOOSING DURABREEZE. YOUR SATISFACTION AND SUCCESS ARE IMPORTANT TO US. CAREFULLY READ THE FOLLOWING INSTRUCTIONS BEFORE USING THIS DURABREEZE INLINE FAN.



## FEATURES

- QUIETLY AND EFFICIENTLY INCREASES AIRFLOW
- THERMALLY PROTECTED MOTOR
- POWDER COATED STEEL HOUSING
- 120V PREWIRED POWER CORD
- 5 YEAR WARRANTY



**4"**

AIRFLOW CFM: 171  
VOLTAGE: 120  
WATTAGE: 108  
AMPERAGE: 0.98  
RPM: 2500  
WEIGHT (LBS): 8.2



**6"**

AIRFLOW CFM: 435  
VOLTAGE: 120  
WATTAGE: 120  
AMPERAGE: 1.0  
RPM: 2500  
WEIGHT (LBS): 10.8



**8"**

AIRFLOW CFM: 745  
VOLTAGE: 120  
WATTAGE: 160  
AMPERAGE: 1.4  
RPM: 2500  
WEIGHT (LBS): 13.7



**10"**

AIRFLOW CFM: 780  
VOLTAGE: 120  
WATTAGE: 185  
AMPERAGE: 1.7  
RPM: 2500  
WEIGHT (LBS): 13.4



**12"**

AIRFLOW CFM: 1060  
VOLTAGE: 120  
WATTAGE: 210  
AMPERAGE: 1.9  
RPM: 2500  
WEIGHT (LBS): 17.2




**WARNING** TO PREVENT SERIOUS PERSONAL INJURY AND DAMAGE TO EQUIPMENT OR OTHER PROPERTY, PLEASE OBSERVE THE FOLLOWING:

- DURABREEZE INLINE FANS ARE TO BE USED ONLY IN ACCORDANCE WITH MANUFACTURER SPECIFICATIONS.
- NEVER EXPOSE THE DURABREEZE INLINE FAN TO TEMPERATURES ABOVE 131°F (55°C) OR RELATIVE HUMIDITY GREATER THAN 70%.
- CONNECT THE DURABREEZE INLINE FAN TO A 120V POWER SOURCE ONLY.
- ALWAYS DISCONNECT UNIT FROM POWER SOURCE PRIOR TO SERVICING AND CLEANING.
- DURABREEZE INLINE FANS ARE FOR GENERAL VENTILATION PURPOSES ONLY. DO NOT USE TO EXHAUST HAZARDOUS OR FLAMMABLE GASES.
- IF UNFAMILIAR WITH THIS TYPE OF APPLICATION, PLEASE CONSULT A CERTIFIED ELECTRICIAN OR CONTACT SUNLEAVES GARDEN PRODUCTS FOR TECHNICAL ASSISTANCE.

## INSTALLATION AND USE

1. BEFORE CONNECTING THE UNIT TO A POWER SOURCE, SPIN THE BLADE TO ENSURE IT IS FREE OF OBSTRUCTIONS AND DOES NOT CATCH ON OR SCRAPE AGAINST THE FAN HOUSING.
2. IDENTIFY AN EASILY ACCESSIBLE LOCATION FOR INSTALLATION OF THE DURABREEZE INLINE FAN. IF NECESSARY, REMOVE A PORTION OF EXISTING DUCTING TO POSITION THE FAN IN PLACE.
3. AS ILLUSTRATED, PLACE SCREWS IN THE MOUNTING BRACKET HOLES AND PLACE THE RUBBER INSERTS, FLAT SIDES DOWN, OVER THE SCREWS WITH THE THINNER EDGES FACING EACH OTHER. RUBBER PADS SHOULD BE BETWEEN THE BRACKET AND THE FAN HOUSING. SECURE THE BRACKET TO THE FAN BY TIGHTENING THE SCREWS WITH A 5/16" SOCKET OR WRENCH. SECURELY MOUNT THE FAN TO A SUPPORTING WALL USING THE ATTACHED MOUNTING BRACKETS.
4. SECURE THE OPEN DUCT ENDS TO THE FAN USING DUCT CLAMPS (SOLD SEPARATELY).
5. ENSURE THE POWER SOURCE IS THE CORRECT VOLTAGE TO AVOID DAMAGING THE FAN MOTOR. PLUG THE DURABREEZE INLINE FAN INTO A PROPERLY GROUNDED 120V OUTLET ONLY.



**NOTE:** TO MAINTAIN OPTIMAL PERFORMANCE, REGULARLY UNPLUG THE FAN AND INSPECT THE IMPELLER FOR OBSTRUCTIONS. WIPE AWAY ANY DIRT OR DEBRIS WITH A DAMP CLOTH.

# ***DuraBreeze Inline Fan Limited Warranty***

## **What This Warranty Covers**

This warranty covers defects in materials and workmanship under normal use, with the exceptions stated below.

## **Who This Warranty Covers**

This warranty applies to the original purchaser of this product with the original proof of purchase.

## **How Long Warranty Coverage Lasts**

This warranty is in effect for a period of 5 years from the original date of purchase.

## **What This Warranty Does Not Cover**

This warranty does not cover damage or defects resulting from the improper installation, alteration, abuse, accidental damage, unauthorized repair or misuse of this product. Misuse includes but is not limited to outdoor use. This warranty does not apply to cosmetic defects or other defects that do not affect the functionality of the product, and is void if the product has been damaged as a result of fire, flood, or other natural disaster. Sunleaves Garden Products ("Sunleaves") shall not be responsible for any incidental or consequential damages of any nature, including damage or injury caused to other products, machinery, buildings or property; loss of profits, time or product; or inconvenience. The original proof of purchase **MUST** accompany the DuraBreeze product for this warranty to be valid. This warranty is given in lieu of all other warranties, express or implied, including without limitation merchantability and fitness for a particular purpose.

***Some states do not allow the exclusion or limitation of incidental and consequential damages, or limitations on how long an implied warranty lasts, so the above limitation(s) may not apply to you.***

## **What Sunleaves Will Do**

If Sunleaves determines the warranted product is defective in materials or workmanship during the warranty period, then Sunleaves, at its option, will either repair or replace the product. In no event shall the cost of repair or replacement exceed the original purchase price.

## **How to Obtain Warranty Service**

Return this product along with the original proof of purchase to the place of purchase in accordance with store policy.

## **How State Law Applies**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**For technical support and warranty information, call toll-free 888-464-9676 or email [info@sunleaves.com](mailto:info@sunleaves.com).**

